



Digital Scanner

Quick Start Guide

Cradle insertion/ features



Connect host interface



Statements

Describe	LED indication	Audio indication	Vibrator indication
Digital scanner			
Power on	Light of bluetooth icon is always on	Beeps	Vibration
Bluetooth connected	Green light of bluetooth icon is always on	Bluetooth connected	\
Bluetooth disconnect	Red light of bluetooth icon flashes	Bluetooth disconnect	\
Decoding succeeded	Green flash	Beeps	\
Decoding transmission failed	Green flash	Error beeps	Vibration
Insert the digital scanner into the cradle	\	Beeps	Vibration
Charging	Red light of battery icon is always on	\	\
High battery	Green light of battery icon is always on	\	\
Find digital scanner	\	Hi, I'm here	Vibration
Cradle			
Bluetooth connected	Green light is always on	\	\
Bluetooth disconnect	Red light is always on	\	\
Insert the digital scanner into the cradle, charging	Red light is always on	\	\
Find digital scanner	Red and green lights flash together	\	\

Основные настройки

Процедура настройки

1

Сканируйте код "Войти в настройки"



ENTERSEI
Открыть Настройки

2

Сканируйте настроечные коды



VISUALSP
USBCDC

3

Сканируйте код "Выйти из настройки"



EXITSETO
Закрыть Настройки

Примечание : Перед началом сканирования настроечных штрихкодов необходимо отсканировать штрихкод "Войти в настройки"

Восстановление заводских настроек

Если Вы забыли какие настройки были сделаны ранее для сканера/базы или если Вы хотите вернуть настройки сканера/базы до заводских - сканируйте расположенные ниже коды, отдельно для сканера и отдельно для базы.



DEFAULTI
Восстановить заводские настройки для сканера



BASFDEFT
Восстановить заводские настройки для базы

Настройка типа коммуникации

Если Вы хотите изменить тип коммуникации, сканируйте соответствующий настроечный штрихкод.



VISUALSP
USBCDC



USBOUTPU
*USBHID

Настройка режима сканирования

Если Вы хотите изменить режим сканирования, сканируйте соответствующий настроечный штрихкод.



MANUALMI

*Сканирование вручную



CONTREAD

Постоянное сканирование

Сканирование вручную: Нажмите на курок и начните считывание штрихкода. Считывание завершится, если декодирование штрихкода прошло успешно, либо отпущен курок или вышел тайм-аут времени сканирования.

Постоянное сканирование: Нажмите кратко на курок, чтобы начать считывание. Для завершения считывания нажмите на курок повторно